



NOTES:

1. SAMPLE POINT SHOULD BE FROM A SERVICE LINE OR FIRE HYDRANT, IF POSSIBLE.
2. AFTER SAMPLING IS COMPLETED AND APPROVED, SHUT OFF CORP. STOP, REMOVE TUBING, PLUG WITH BRASS PLUG AND LOCATE FOR RECORD DRAWINGS.

LBFH INC. - CADD FILE NAME: L:\CAD-DETAILS\SLC\SLC-W8.DWG



**ST. LUCIE COUNTY
WATER & WASTEWATER
CONSTRUCTION STANDARDS**

**TEMPORARY
SAMPLE POINT DETAIL**

DRAWING NUMBER: **W-8**